




# Instructions for 1000DX-200, 1001DX-200, 1003DX, 1005DX Speedster®



Please read before use.



Register your product  
at <http://www.mytee.com/support/register>



1000DX-200 p.3  
1001DX-200 p.9  
1003DX p.15  
1005DX p.21  
General information p.27

Model # \_\_\_\_\_


Serial # \_\_\_\_\_

Form # ADP-Speedster

1-15




## 1000DX-200 SPEEDSTER® FRONT




- 1. Switch plate
- 2. Easy faucet fill
- 3. Solution tank lid
- 4. Front handle
- 5. Front vent
- 6. 5" locking casters
- 7. Solution tank
- 8. Female quick disconnect
- 9. 2" Male Cuff-Lynx™
- 10. Recovery lid

## 1000DX-200 SPEEDSTER® BACK




- 11. Recovery tank
- 12. Push handle
- 13. Drain valve
- 14. Power cord
- 15. Back vent
- 16. 12" Rear wheels


## 1000DX-200 SPEEDSTER® ITEMS INCLUDED



H110 Cuff-Lynx™  
2" Hose Adapter



H141 Cuff-Lynx™  
2" Hose Reducer to 1.5"




H375 - Hose Hanger  
(4) screws



H226 Drain Elbow


## 1000DX-200 SPEEDSTER® CORD



Plug the power cord into a single, 20A grounded wall outlet.


# 1000DX-200 SPEEDSTER

## 1000DX-200 SPEEDSTER® VAC/SOL HOSE CONNECTIONS




Attach one end of a solution hose to a wand or other tool, the other end to the Speedster's® front quick disconnect. Attach one end of a vacuum hose to the tool, the other end to the Speedster's® Cuff-Lynx™ vacuum hose port.

## 1000DX-200 SPEEDSTER® SWITCHES




Turn on Vac 1, Vac 2 and Pump switches.

## 1000DX-200 SPEEDSTER® FILL SOLUTION TANK




Lift lid and manually fill the solution tank or use the easy faucet fill.

## 1000DX-200 SPEEDSTER® FLOAT SWITCH




The Speedster® is equipped with an electronic float switch inside the recovery tank. The recovery float switch is activated by rising water to prevent suction into the vacuum stacks damaging the motors.

## 1000DX-200 SPEEDSTER® DUMP VALVE




Attach the 45° drain elbow to the drain spout in back. Lift up the dump valve and empty the tank.

## 1000DX-200 SPEEDSTER® FILTER MAINTENANCE




Check and clean the vacuum stack filters and solution tank filter daily by twisting off, rinsing with clean water and replacing.

## 1000DX-200 SPEEDSTER® LOCKING CASTERS



Locking casters help keep the machine remain stationary during use.


## MYTEE® SYSTEM MAINTAINER



Weekly flushing of the solution system with Mytee® System Maintainer helps keep lines clean and prevents chemical build-up, improving pump life, performance and pressure.

# 1000DX-200 SPEEDSTER PARTS & PRICING

ITEM NO.	PART NO.	DESCRIPTION	QTY.	MSRP	ITEM NO.	PART NO.	DESCRIPTION	QTY.	MSRP
1	C317	fan, cooling, 115V screw, #10x5/8" hex head, zinc	1	\$21.49 ea	56	PH634-36	sol hose, 1/4", silicone braided, clear	1	\$6.49 ff
2	H343	guard, cooling fan, wire	12	\$0.99 ea	57	H485	handle, breeze and dx bracket, front hinge, sp/fb	1	\$6.99 ea
3	H296	screw, 10-32 x 3/4", phil flat full thread	3	\$2.99 ea	58	H378	filter, strainer, 1/2"	1	\$8.99 ea
F	H186	controller, water level dual pump or vac nut, kep, #10-32 zinc	1	\$9.499 ea	59	B119A	bushing, brass, 1/2"mpt x 3/8" fpt, hex	1	\$8.49 ea
5	E370	wheel, 10-32, nylon insert, 5/8"	8	\$0.99 ea	60	B210	nipple, brass, 3/8" x close	1	\$2.49 ea
6	H273	nut, lock, 1/4-20, nylon insert, 5/8"	10	\$0.99 ea	61	B216	spout, drain, 45 degree valve, drain, 1-1/2"	1	\$1.99 ea
7	H216	washer, 1/4" flat, 5/8"	22	\$0.99 ea	62	H226	vac tank, speedster	1	\$3.19 ea
8	H210	bolt, 1/4-20 x 1" hex head, 5/8" c-clip, 5/8" black hub & gray tread	8	\$0.99 ea	63	H225	vac tank, speedster	1	\$20.99 ea
9	H342	caster, 5", black hub & grey tread	2	\$23.19 ea	64	P733	nut, lock, 1-1/2", steel pipe, pvc, 1-1/2"	2	\$1.99 ea
10	H666	nut, lock, 1/2" steel	1	\$0.99 ea	65	H314	pipe, pvc, 1-1/2"	4	\$4.99/ft
E	H371	fitting, strain relief, cord	1	\$3.19 ea	66	PH633-03	pipe, pvc, 1-1/2"	2	\$4.99/ft
11	H254	washer, axle, cut 1/2" id wheel, 12"	4	\$0.99 ea	67	PH633-4	adapter, 1.5" pvc, fsip x fsip	2	\$3.00 ea
12	H251	power cord, pigtail, 30", 12/3, black base, speedster	2	\$41.99 ea	68	P502	adapter, pvc, 1-1/2" mpt x 1-1/2" fms	2	\$4.99 ea
13	H042	bolt, 1/4-20 x 3/4" hex head, 5/8" c-clip, 12mm, external	2	\$0.99 ea	69	G097	screen, mesh filter, 1-1/2" dia	2	\$1.99 ea
14	H221	soil hose, 1/2" kuri 10psi	1	\$1.99 ea	70	G003	filter, foam, 2" x 50" o.d.	2	\$1.99 ea
15	H220	female, 1/2", brass	2	\$0.99 ea	71	PH633-1	pipe, pvc, 1-1/2"	2	\$4.99/ft
16	H550	power cord, pigtail, 30", 12/3, black	1	\$1.149 ea	72	P503	adapter, 1.5" pvc, 45 deg, fsip x fsip	4	\$3.29 ea
17	P731	base, speedster	1	\$141.99 ea	73	P520	adapter, pvc, 1-1/2" mpt x 1-1/2" fms	2	\$2.99 ea
18	H202	elbow, brass, 90 deg, 3/8"mpf x 3/8" fsw, ball end	1	\$8.99 ea	74	G090	lid, vac tank, clear, 7"	1	\$36.99 ea
19	P1615-26	elbow, brass, 90 deg, 1/4" fpt	1	\$8.99/ft	75	H304	screw, #8 x 5/8" phil oval, s/s	6	\$0.99 ea
20	AH120	elbow, brass, 90 deg, 1/4" mpf x 1/4" fpt	2	\$35.49 ea	76	G091	gasket, 7", vac lid	1	\$11.99 ea
21	B173	elbow, brass, 90 deg, 1/4" fpt x 1/4" fpt	1	\$4.99 ea	77	A926	elbow, inlet assembly, 2"	1	\$15.99 ea
22	B160	elbow, brass, 90 deg, 3/8"mpf x 3/8" fsw, ball end	1	\$3.49 ea	78	G083	gasket, 2" inlet	1	\$2.49 ea
D	B186	elbow, brass, 90 deg, 3/8"mpf x 3/8" fsw, ball end	1	\$8.99 ea	79	H135	Cuff-Lynx, 2" m cuff x 2"mpf	1	\$3.99 ea
23	AH120	elbow, brass, 90 deg, 1/4" mpf x 1/4" fpt	2	\$35.49 ea	80	H765	plug, vent, neyco, 1/2"	2	\$0.99 ea
24	B136	elbow, brass, 90 deg, 1/4" mpf x 1/4" fpt	1	\$4.99 ea	81	E515	switch, rocker, 2 position	3	\$13.99 ea
25	B105	bushing, brass, 3/8"mpf x 1/4" fpt	1	\$3.19 ea	82	P967A	plugs	1	\$1.99 ea
26	H299	washer, 11/16"dia x 1-1/2" od x .075, s/s	4	\$0.99 ea	83	H389	screw, 10-32 x 1/2" SHCS, alloy	3	\$0.99 ea
27	H222	screw, 10-32 x 1/4" phil pan head, s/s	4	\$0.99 ea	84	H612	Washer, #8, flat regular	3	\$0.99 ea
28	C322D	pump, 220psi, diag pump, 15V	1	\$208.99 ea	85	H434	plug, vent, neyco, 1/2"	1	\$4.48 ea
29	C307	washer, star, 1/4" steel zinc	2	\$0.99 ea	86	H348	plate, switch, 1000DX-200	1	\$6.99 ea
30	B172	washer, buna 1-1/8" od x 3/16" id	6	\$1.99 ea	87	B156	nut, 1/4" npf	1	\$1.99 ea
31	H912	washer, 1/4" id x 1/4" flat, s/s	6	\$0.99 ea	88	H212	flat washer, 9/16"ID x 1 1/16"OD	1	\$0.99 ea
32	H770	bracket, rear, fb/spy	1	\$0.99 ea	89	E373	level switch, vacuum shutoff, rear threads	1	\$13.99 ea
C	H307	bolt, 1/4-20 x 1/2" serrated hex flange, zinc	4	\$0.99 ea	90	B207	elbow, brass, 90 deg, 1/4" fpt x 1/4" fpt	1	\$5.99 ea
33	G052	washer, star, 1/4" steel zinc	2	\$0.99 ea	91	H390A	nut, 1/4" npf	2	\$6.99 ea
34	H211	washer, buna 1-1/8" od x 3/16" id	6	\$1.99 ea	92	H034	plastic screw, 1/4 x 1"	4	\$0.99 ea
35	H124	washer, 1/4" id x 1/4" flat, s/s	6	\$0.99 ea	93	H096	bolt, hex, 1/4-20 x 4", zinc	6	\$0.99 ea
36	H194	Cuff-Lynx, 2" m cuff x 2" female cuff	2	\$3.99 ea	94	H503	vac support, 3 stage, 3.25", no thirds	6	\$3.99 ea
37	H217	coupler, 2" dia x 2.5" length, s/s	2	\$10.00 ea	95	C302LA	vac motor, 3 stage, low amp	2	\$139.99 ea
38	H628-24	clamp, hose, 2-1/4" dia	4	\$1.49 ea	96	G004	vacuum motor	2	\$8.99 ea
39	H213	vac hose, 2", wire reinforced	1	\$8.99/ft					
40	H215	washer, 1/4" lock, s/s	10	\$0.99 ea					
41	P4612-36	nut, hex, 1/4-20 s/s	2	\$0.99 ea					
42	H178	clear tubing, 1/2" OD x 3/8" ID, faucet fill	1	\$1.99/ft					
B	G019	faucet fill	1	\$1.99 ea					
43	G018	cover, sol tank (sp)	1	\$12.99 ea					
44	P732	sol tank, speedster	1	\$141.99 ea					
45	H768	bolt, 1/4-20 x 3/4" serrated hex flange, zinc	2	\$0.99 ea					
46	B107	nipple, brass, 1/4"m, hex	3	\$3.19 ea					
47	H484	plate, mounting, QD	1	\$4.99 ea					
48	H256	screw, 10-32 x 3/4" phil pan head, zinc	4	\$0.99 ea					
49	B142	coupling, brass, 1/4" fpt x 1/4" fpt	1	\$4.49 ea					
50	B135	tee, brass, 1/4" f x 1/4" f	1	\$5.49 ea					
51	B102	qd, brass, 1/4" f x 1/4" f	1	\$17.99 ea					
52	B656	ball valve, 1/4"	1	\$13.49 ea					
53	B109	adapter, brass, 1/4" barb x 1/4" mpt	1	\$1.99 ea					
54	B170	fitting, 1/4" brass	1	\$0.99 ea					
55									




speedster

SHEET DWG. NO. REV  
C 1000DX-200 F  
DRAWN: 10/20/2013  
CHECKED: 10/20/2013  
COMMENTS: SHEET 1 OF 3

Order parts at: [www.mytee.com/products/product.php?id=1000DX](http://www.mytee.com/products/product.php?id=1000DX)

Part prices are subject to change.

# 1000DX-200 SPEEDSTER PARTS & PRICING



mytee PRODUCTS, INC.	
NAME M1000DX200	DATE 10/20/13
CHECKED	TITLE 558-572-191
COMMENTS	REV F

**speedster**

PROGRESSIVE AND CONFIDENTIAL DRAWINGS & THE EQUIVALENT OF TRADE SECRETS OF MYTEE PRODUCTS, INC. ARE THE PROPERTY OF MYTEE PRODUCTS, INC. AND ARE NOT TO BE COPIED OR REPRODUCED IN WHOLE OR IN PART WITHOUT THE WRITTEN PERMISSION OF MYTEE PRODUCTS, INC. S

SIZE DWG. NO.  
**C 1000DX-200**

SCALE: 1:48


DRAWN: 10/20/13

REV: F


SCHEMATIC: SHEET 2 OF 3

# 1000DX-200 SPEEDSTER WIRING SCHEMATIC

## 1000DX-200 115 Volt System




## 1001DX-200 SPEEDSTER® FRONT




1. Switch plate  
2. Easy faucet fill  
3. Solution tank lid  
4. Front handle  
5. Front vent  
6. 5" locking casters  
7. Solution tank  
8. Female quick disconnect  
9. 2" Male Cuff-Lynx™  
10. Recovery lid

## 1001DX-200 SPEEDSTER® BACK




11. Recovery tank  
12. Push handle  
13. Drain valve  
14. Dual power cords  
15. Back vent  
16. 12" Rear wheels


## 1001DX-200 SPEEDSTER® ITEMS INCLUDED



H110 Cuff-Lynx™  
2" Hose Adapter



H141 Cuff-Lynx™  
2" Hose Reducer to 1.5"




H375 - Hose Hanger  
(4) screws



H226 Drain Elbow

## 1001DX-200 SPEEDSTER® CORDS


**Left cord:** Powers Vac 2 & Heater 2.  
**Right cord:** Powers Vac 1, Heater 1 & Pump.



Plug each power cord into a separate, 20A grounded wall outlet. **Outlets must be on two separate breakers.** When the amber light on the switch plate illuminates, the machine is on separate circuits (not necessarily 20A circuits). You can identify the primary cord by the yellow tag.


# 1001DX-200 SPEEDSTER

## 1001DX-200 SPEEDSTER® VAC/SOL HOSE CONNECTIONS




Attach one end of a solution hose to a wand or other tool, the other end to the Speedster's® front quick disconnect. Attach one end of a vacuum hose to the tool, the other end to the Speedster's® Cuff-Lynx™ vacuum hose port.

## 1001DX-200 SPEEDSTER® SWITCHES




"On" switches are located on the plate in front of the machine. To use vacuums, turn on Vac 1 and Vac 2 switches. To use pump, turn on Pump switch. To activate heat, turn on Heater switch. Heater 1 for 1000 watts of heat. Heater 2 for 2000 watts of heat.

## 1001DX-200 SPEEDSTER® FILL SOLUTION TANK




Lift lid and manually fill the solution tank or use the easy faucet fill.

## 1001DX-200 SPEEDSTER® FILTER MAINTENANCE




Check and clean the vacuum stack filters and solution tank filter daily by twisting off, rinsing with clean water and replacing.

## 1001DX-200 SPEEDSTER® FLOAT SWITCH




The Speedster® is equipped with an electronic float switch inside the recovery tank. The recovery float switch is activated by rising water to prevent suction into the vacuum stacks damaging the motors.

## 1001DX-200 SPEEDSTER® DUMP VALVE




Attach the 45° drain elbow to the drain spout in back. Lift up the dump valve and empty the tank.

## 1001DX-200 SPEEDSTER® LOCKING CASTERS




Locking casters help keep the machine remain stationary during use.

## MYTEE® SYSTEM MAINTAINER



Weekly flushing of the solution system with Mytee® System Maintainer helps keep lines clean and prevents chemical build-up, improving pump life, performance and pressure.

# 1001DX-200 SPEEDSTER PARTS & PRICING



ITEM NO.	PART NO.	DESCRIPTION	QTY.	MSRP	ITEM NO.	PART NO.	DESCRIPTION	QTY.	MSRP	
1	C317	fan, cooling, 115V screw, #10 5/8" hex head, zinc	1	\$21.49 ea	63	B656	ball valve, 1/4"	1	\$13.49 ea	
2	H343	guard, cooling fan, wire nut, kep. #10-32 zinc	12	\$0.99 ea	64	B109	adapter, 1/4" Barb x 1/4" mpt	1	\$1.99 ea	
3	H296	screw, 10-32 x 3/4", phil flat full thread nut, lock, 1/4-20, nylon insert, s/s	3	\$2.99 ea	65	B170	female, 1/4" brass	2	\$0.99 ea	
F	4	H186	screw, 10-32 x 3/4", phil flat full thread controller, water level dual pump or vac bolt, 1/4-20 x 1" hex head, s/s	2	\$0.99 ea	66	PH634-20	so hose, 1/4", silicone braided, clear	1	\$6.49 ft
F	5	E370	nut, lock, 1/4-20, nylon insert, s/s	1	\$94.99 ea	67	H485	handle, breeze end ck	1	\$6.99 ea
F	6	H273	washer, 1/4" flat, s/s	10	\$0.99 ea	68	H201	bolt, 1/4-20 x 1/2", hex head, zinc	2	\$0.99 ea
F	7	H216	washer, 1/4" flat, s/s	10	\$0.99 ea	69	H378	bracket, front thingie, sp/flo	1	\$8.99 ea
F	8	H210	washer, 1/4" flat, s/s	22	\$0.99 ea	70	H316	bolt, 1/4x1-1/2", hex head zinc	2	\$0.99 ea
F	9	H342	bolt, 1/4-20 x 1" hex head, s/s castier, 5" Black hub & gray tread	8	\$0.99 ea	71	B119A	filter, strainer, 1/2"	1	\$6.49 ea
F	10	H666	bases, 5" Black hub & gray tread	2	\$23.19 ea	72	B210	bushing, brass, 1/2"mpt x 3/8" fpt, hex	1	\$2.49 ea
F	11	P731	base, speedster	1	\$14.99 ea	73	B216	nipple, brass, 3/8" x close	1	\$1.99 ea
F	12	H371	axle, 18.03" x .50" dia	1	\$9.99 ea	74	H226	spout, drain, 45 degree	1	\$3.19 ea
F	13	I254	washer, axle, cut 1/2" id	4	\$0.99 ea	75	H225	valve, drain, 1-1/2"	1	\$20.99 ea
F	14	H251	wheel, 1/2"	2	\$41.99 ea	76	P733	vac tank, speedster	1	\$190.99 ea
F	15	H042	c-clip, 12mm, extenal	2	\$0.99 ea	77	A926	elbow, inlet assembly 2"	1	\$5.99 ea
F	16	AH156	hose, pulse, 3/8" x 17-1/2" (OAL), f hose, 3/8", (OAL), f x ls, 5/400 grey	1	\$31.99 ea	78	PHE633-4	pipe, pvc, 1-1/2"	2	\$4.99 ft
F	17	AH156	elbow, brass, 90 deg, 1/4"mpt x 1/4" fpt	2	\$4.49 ea	79	PH633-03	PIPE, 1-1/2" x 6" PVC	2	\$4.99 ft
F	18	B103	screw, 10-32 x 3/4", phil pan head, zinc bracket, heater mounting, dual	6	\$0.99 ea	80	PH633-06	adapter, 1.5" pvc, felp x felp	2	\$5.00 ea
F	19	H256	heating rod, 1000W, 115v	1	\$29.99 ea	81	P502	screen, mesh filter, 1-1/2" dia	2	\$4.99 ea
F	20	H528	coupling, brass, 1/4" fpt x 1/4" fpt	2	\$51.99 ea	82	G097	filter, foam, 2" x .50" o.d.	2	\$1.99 ea
F	21	E519	valve, brass, 1/4" check	1	\$4.49 ea	83	G003	pipe, pvc, 1-1/2"	2	\$4.99 ft
F	22	B142	nut, lock, 1/2" steel	2	\$13.99 ea	84	PH633-1	gasket, 7", vac lid	1	\$1.99 ea
F	23	B108	fitting, strain relief, cord	2	\$0.99 ea	85	G091	lid, vac tank, clear, 7"	1	\$36.99 ea
F	24	H274	heater, aluminum cast, single power cord, 3/8" x 12", black	2	\$78.99 ea	86	G090	screw, #8 x 5/8" phil oval, s/s	6	\$0.99 ea
D	25	H903A	Thermostat, 310°F ± 10°F, Manual, 1/4"	2	\$16.49 ea	87	H304	adapter, 1.5" deg, felp x felp	4	\$3.29 ea
D	26	E573	Thermostat, 310°F ± 10°F, Manual, 1/4"	2	\$17.99 ea	88	P503	adapter, pvc, 1-1/2" mpt x 1-1/2" fms	2	\$2.99 ea
D	27	E574	sol hose, 28" x 1/4", 1/4" fpt	2	\$35.49 ea	89	P520	nut, lock, 1-1/2", steel	2	\$1.99 ea
D	28	AH120	elbow, brass, 90 deg, 3/8"mpt x 3/8" fmp	1	\$1.99 ea	90	H314	gasket, 2" inlet	1	\$2.49 ea
D	29	H221	bushing, brass, 90 deg, 1/4"mpt x 1/4" fmp	1	\$4.99 ea	91	G083	Cuff-Lynx, 2" mft cuff x 2" mpt	1	\$3.99 ea
D	30	H220	bushing, brass, 90 deg, 1/4"mpt x 1/4" fmp	2	\$11.49 ea	92	H315	light, red, 250v	2	\$5.99 ea
D	31	E550	bracket, rear, fb/soy	1	\$8.99 ft	93	E511	switch, rocker, 3 position	1	\$14.99 ea
D	32	PH615-26	adapter, brass, 1/2" Barb x 3/8" fsw, ball end	1	\$3.49 ea	94	E516	switch, rocker, 2 position	3	\$13.99 ea
D	33	B160	elbow, brass, 90 deg, 3/8"mpt x 3/8" fmp	1	\$8.99 ea	95	E515	light, indicator, 125v, (amber)	1	\$9.99 ea
D	34	B186	bushing, brass, 90 deg, 1/4"mpt x 1/4" fmp	1	\$3.19 ea	96	E512B	screw, 10-32 x 1/2" SHCS, alloy	4	\$0.99 ea
D	35	B136	bushing, brass, 90 deg, 1/4"mpt x 1/4" fmp	1	\$4.99 ea	97	H389	Washer, #8, flat regular	3	\$0.99 ea
D	36	B105	bracket, rear, fb/soy	1	\$9.99 ea	98	H612	plate, switch, 1000DX-200	1	\$6.99 ea
D	37	H299	washer, 1 1/16" id x 1-1/2" od x .075", s/s	4	\$0.99 ea	99	H348	nut, 1/4" npt	1	\$1.99 ea
D	38	H222	screw, 10-32 x 1-1/4", phil pan head, s/s	4	\$0.99 ea	100	B156	flat washer, 9/16"ID x 1 1/16"OD	2	\$0.99 ea
D	39	C322D	pump, 220psi, diaphragm, 1.5V	1	\$208.99 ea	101	H212	level switch, vacuum, rear threads	1	\$13.99 ea
D	40	B172	elbow, brass, 90 deg, 1/2" Barb x 3/8"mpt	1	\$9.49 ea	102	E373	elbow, brass, 90 deg, 1/4" fpt x 1/4" fpt	1	\$5.99 ea
D	41	H213	female, 1/2", brass	2	\$0.99 ea	103	B207	bracket, 1"	2	\$6.99 ea
D	42	H912	bracket, rear, fb/soy	1	\$9.99 ea	104	H390A	bolt, hex, 1/4-20 x 4", zinc Finish	6	\$0.99 ea
D	43	H770	bolt, 1/4-20 x 1/2" serrated hex flange, zinc	8	\$0.99 ea	105	H096	vac support, 3 stage, 3.25", no hds	6	\$3.99 ea
D	44	H307	washer, star, 1/4" steel zinc	2	\$0.99 ea	106	H503	vac motor, 3 stage, low amp	2	\$139.99 ea
D	45	G052	washer, buna, 1-1/8" od x 3/16" id	6	\$1.99 ea	107	C202LA	gasket, vacuum motor	2	\$8.99 ea
D	46	H211	washer, 1/4" id x 1-1/4" od, flct, s/s	6	\$0.99 ea	108	G004	controller, circuit light	1	\$62.99 ea
D	47	H203	bolt, 1/4-20 x 1/4"	2	\$0.99 ea	109	E564			
D	48	H124	Cuff-Lynx, 2" mft x 2" female cuff coupler, 2" dia x 2.5" length, s/s	2	\$3.99 ea					
D	49	H194	clamp, hose, 2-1/4 dia	4	\$1.49 ea					
D	50	H217	vac hose, 2", wire reinforced	2	\$8.99 ft					
D	51	PH628-15	washer, 1/4" lock, s/s	10	\$0.99 ea					
D	52	H213	nut, hex, 1/4-20 s/s	2	\$0.99 ea					
D	53	H215	cover, sol tank SP	1	\$12.99 ea					
D	54	G018	clear tubing, 1/2" OD x 3/8" ID, faucet fill	1	\$1.99 ft					
D	55	PH612-36	faucet fill	1	\$1.99 ea					
D	56	H178	hanger, wire formed, hose	1	\$10.99 ea					
D	57	P732	screw, 10-32 x 1/2" phl pan head, s/s	2	\$0.99 ea					
D	58	H768	bolt, 1/4-20 x 3/4" serrated hex flange, zinc	2	\$0.99 ea					
D	59	B107	nipple, brass, 1/4"m, hex	3	\$3.19 ea					
D	60	H844	plate, mounting, QD tee, brass, 1/4" mpt	1	\$5.49 ea					
D	61	B135	tee, brass, 1/4" mpt	1	\$7.49 ea					
D	62	B102	qd, brass, 1/4" fpt x 1/4" fpt	1	\$17.99 ea					

ITEMS NOT SHOWN

PART NO.	DESCRIPTION	QTY	MSRP
G008	piglet filter	1	\$6.29 pk
H375	hanger, wire formed, hose	1	\$10.99 ea
H230	screw, 10-32 x 1/2" phl pan head, s/s	2	\$0.99 ea
H141	Cuff-Lynx, 2" x 1.5" reducer	1	\$3.99 ea
H110	Cuff-Lynx, 2" hose x 2" tem swivel Cuff-Lynx	1	\$3.99 ea
E530	power cord, ext 30' 12/3 block	2	\$74.99 ea

SIZE DWG. NO. REV. SHEET 1 OF 3

C 1001DX-200 E

SCALE 1:48

DRAFTS ARE FOR INFORMATION PURPOSES ONLY. THEY ARE NOT DRAWINGS AND ARE NOT TO BE USED FOR CONSTRUCTION OR AS A SUBSTITUTE FOR AN AS-BUILT DRAWING. THE CONTRACTOR IS RESPONSIBLE FOR ALL CONSTRUCTION ACTIVITIES.

mytee PRODUCTS, INC.


TITLE: 888-555-1234

Part prices are subject to change.

speedster

Order parts at: [www.mytee.com/products/product.php?id=1001DX](http://www.mytee.com/products/product.php?id=1001DX)

# 1001DX-200 SPEEDSTER PARTS & PRICING




mytee PRODUCTS, INC.	REV E
888-877-1111	TITLE: speedster
DRAWN M. LeBarbera	DATE 10/20/13
CHECKED	
PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF REFCO, INC. IT IS TO BE KEPT CONFIDENTIAL AND NOT DISCLOSED OR COPIED EXCEPT WITH THE EXPRESS WRITTEN PERMISSION OF REFCO, INC.	
SIZE C 1001DX-200	SCALE 1:48
500203.00	SHEET 2 OF 3

# 1001DX-200 SPEEDSTER WIRING SCHEMATIC


Speedster 1001DX-200

115 Volt


Power In  
1



Power In  
2




## 1003DX SPEEDSTER® FRONT




1. Switch plate  
2. Easy Faucet Fill  
3. Solution lid  
4. Front handle  
5. Front cooling fan  
6. Pressure Regulator  
7. Solution tank  
8. Female QD with Prime Valve  
9. 2" Male Cuff-Lynx™  
10. Recovery lid

## 1003DX SPEEDSTER® BACK




11. Push handle  
12. Recovery tank  
13. Drain valve  
14. Dual Power cords  
15. 12" Rear wheels  
16. Back vent  
17. 5" locking casters


## 1003DX SPEEDSTER® ITEMS INCLUDED



H110 Cuff-Lynx™  
2" Hose Adapter



H141 Cuff-Lynx™  
2" Hose Reducer to 1.5"




H375-Hose Hanger  
(4) screws



H226 Drain Elbow

## 1003DX SPEEDSTER® CORD


**Left cord:** Powers Vac 2 & Heater 2.  
**Right cord:** Powers Vac 1, Heater 1 & Pump.



Plug each power cord into a separate, 20A grounded wall outlet. **Outlets must be on two separate breakers.** When the amber light on the switch plate illuminates, the machine is on separate circuits (not necessarily 20A circuits). You can identify the primary cord by the yellow tag.


# 1003DX SPEEDSTER

## 1003DX SPEEDSTER® VAC/SOL HOSE CONNECTIONS




Attach one end of a solution hose to a wand or other tool, the other end to the Speedster's® front quick disconnect. Attach one end of a vacuum hose to the tool, the other end to the Speedster's® Cuff-Lynx™ vacuum hose port.

## 1003DX SPEEDSTER® SWITCHES




"On" switches are located on the plate in front of the machine. To use vacuums, turn on Vac 1 and Vac 2 switches. To use pump, turn on Pump switch. To activate heat, use lower right switch. Press to the left for 1,000 watts, press to the right for 2,000 watts.

## 1003DX SPEEDSTER® FILL SOLUTION TANK




Lift lid and manually fill the solution tank or use the easy faucet fill.

## 1003DX SPEEDSTER® PRIME VALVE & PRESSURE REGULATOR




Prime the pump by turning the valve to the Prime position (as shown above) for 30 seconds, then turn right to the Run position. Turn the Pressure Regulator to the left to decrease water pressure. Turn the Pressure Regulator to the right to increase water pressure.

## 1003DX SPEEDSTER® FILTER MAINTENANCE




Check and clean the vacuum stack filters and solution tank filter daily by twisting off, rinsing with clean water and replacing.

## 1003DX SPEEDSTER® FLOAT SWITCH




The Speedster® is equipped with an electronic float switch inside the recovery tank. The recovery float switch is activated by rising water to prevent suction into the vacuum stacks damaging the motors.

## 1003DX SPEEDSTER® DUMP VALVE & LOCKING CASTERS



Above, empty the recovery tank by attaching the 45° drain elbow to the drain spout in back. Lift up the dump valve and empty the tank. Below, locking casters help keep the machine remain stationary during use.

## MYTEE® SYSTEM MAINTAINER




Weekly flushing of the solution system with Mytee® System Maintainer helps keep lines clean and prevents chemical build-up, improving pump life, performance and pressure.

# 1003DX SPEEDSTER PARTS & PRICING

ITEM NO.	PART NO.	DESCRIPTION	QTY.	MSRP	ITEM NO.	PART NO.	DESCRIPTION	QTY.	MSRP	ITEM NO.	PART NO.	DESCRIPTION	QTY.	MSRP
1	C317	fan, cooling, 1.5V	1	\$21.49 ea	70	H123	washer, 1/4" lock, #5	10	\$0.99 ea	71	H125	washer, 1/4" lock, #5	2	\$0.99 ea
2	H276	guard, cooling fan, wire	3	\$0.99 ea	71	H125	washer, 1/4" lock, #5	2	\$0.99 ea	72	A1085	screw, 1/4" x 24 (72) (ONL)	1	\$26.29 pk
3	H143	screw, 10-32 x 1/4, flat head	12	\$0.99 ea	73	H144	plate, mounting, QD	1	\$4.49 ea	73	H144	plate, mounting, QD	1	\$0.99 ea
4	H166	coupler, water, dual port, orvac	4	\$0.99 ea	74	H142	coupling, brass, 1/4" fl x 1/4" fl	1	\$4.49 ea	75	H135	qd brass, 1/4" x 1/4" [tp]	1	\$4.49 ea
5	E370	null, kep, #14-20, nylon insert, .35	1	\$0.99 ea	76	B102	qd brass, 1/4" x 1/4" [tp]	1	\$1.79 ea	76	H120	scREW, 10-32 x 1/2" plain pan head, #5	2	\$0.99 ea
6	H273	null, loc, #14-20, nylon insert, .35	8	\$0.99 ea	77	B166	ball valve, 1/4" x 1/4"	1	\$1.49 ea	78	H141	Off-LyNk, 1/4" x 1/4" [tp] reducer	1	\$3.99 ea
7	H216	null, loc, #14-20, "T" hex head, #5	14	\$0.99 ea	78	B102	coupler, brass, 1/4" fl x 1/4" m/c	1	\$1.79 ea	79	E530	power cord, ext, 50', 120s black	2	\$17.99 ea
8	H210	washer, 1/4-20 x 1" hex head, #5	26	\$0.99 ea	79	F102	bushing, brass, 1/4" bush x 1/4" m/c	1	\$1.79 ea	80	H112	Cuff-LyNk, 2" hose x 2" ferm swivel Cuff-LyNk	1	\$3.99 ea
9	H282	bolt, 1/4-20 x 1" hex head, #5	12	\$0.99 ea	80	F102	scREW, 1/4" hex cap x 1/4" m/c	1	\$1.79 ea	81	AD122	shop sign, regular cut, printed	1	\$4.49 ea
10	H466	coupler, 5/8" Brass hub & 8" Ray Head	2	\$23.19 ea	81	F145	hand, breeze, and dk	1	\$4.49 ea	82	AD1003DX	manual speedster	1	\$4.49 ea
11	E564	washer, o-die, cut 1/2" id	1	\$0.99 ea	81	H131	boot, 1/4" x 1/2", heat shrink zinc	2	\$0.99 ea	82	H138	bracket, front hinge, stiff/b	1	\$0.99 ea
12	H254	axis, 18.03 x 3/4" dia	6	\$0.99 ea	83	I201	bolt, 1/4-20 x 1/2" hex head, zinc	2	\$0.99 ea	83	H201	bolt, 1/4-20 x 1/2" hex head, zinc	2	\$0.99 ea
13	H371	wheel, 12"	2	\$41.99 ea	84	I209	washer, 1/16" x 1/2" x .075, zinc	4	\$0.99 ea	85	B121	imp. brass, 3/8" x 1/2"	1	\$1.79 ea
14	H251	c-cd, 12mm, extend	2	\$0.99 ea	85	B116	bushing, brass, 3/8" x 1/2"	1	\$2.49 ea	86	B120	bushing, brass, 1/2" m/c x 3/8" fl x hex	1	\$2.49 ea
15	H402	null, loc, 1/2" steel	2	\$0.99 ea	86	B119A	filter, filter, 1/2"	1	\$4.49 ea	87	P134	flange, loc, 1/2", heat shrink	2	\$1.79 ea
16	H221	fitting, flared, flared, cord	2	\$0.19 ea	88	F134	flange, loc, 1/2", heat shrink	2	\$1.79 ea	89	F138	adapter, pvc, 1/2" m/c x 1/2" fl	2	\$2.49 ea
17	H220	power cord, Digital, 30' black	1	\$14.99 ea	90	H120	adapter, pvc, 1/2" m/c x 1/2" fl	2	\$2.49 ea	90	H133-C3	pipe, pvc, 1/2"	2	\$4.99 ft
18	H550	power cord, Digital, 30' black	1	\$14.99 ea	91	F102	adapter, brass, 1/2" m/c x 1/2" fl x iso	2	\$5.00 ea	91	F102	adaptor, brass, 1/2" m/c x 1/2" fl x iso	2	\$5.00 ea
19	P231	thermostat, 30°F ± 10°F Manual, 1/4"	2	\$17.99 ea	92	F109	screen, mesh filter, 1/2" do	2	\$4.49 ea	92	G097	screen, mesh filter, 1/2" do	1	\$1.79 ea
20	H256	screw, 1/4-20 x 3/4" dia, pan head, zinc	6	\$0.99 ea	93	F109	filter, screen, 1/2" do	2	\$4.49 ea	94	C003	filter, locm, 2" x 50" od.	2	\$1.79 ea
21	H258	bracket, header mounting, dk	1	\$28.99 ea	95	F134	flange, pvc, 1/2" m/c	2	\$4.99 ft	95	F133	flange, pvc, 1/2" m/c	2	\$4.99 ft
22	H403A	header, aluminum, cast, single	2	\$76.99 ea	96	F138	flange, pvc, 1/2"	2	\$4.99 ft	96	F133-06	flange, pvc, 1/2" x 6"	2	\$4.99 ft
23	H259	heating rod, 12.00W, 115V	1	\$0.99 ea	97	F138	flange, pvc, 1/2" x 6"	2	\$4.99 ft	97	F133-06	flange, pvc, 1/2" x 6"	2	\$4.99 ft
24	E574	thermostat, 30°F ± 10°F Manual, 1/4"	2	\$17.99 ea	98	F122	flange, pvc, 1/2" x 6"	1	\$3.19 ea	98	F122	flange, pvc, 1/2" x 6"	1	\$3.19 ea
25	H274	screw, 1/4-20 x 3/4" dia, pan head, self-tapping	10	\$0.99 ea	99	F102	flange, pvc, 1/2" x 6"	1	\$3.19 ea	99	F102	flange, pvc, 1/2" x 6"	1	\$3.19 ea
26	E573	thermost, 30°F ± 10°F	2	\$16.49 ea	100	F126	flow assembly, 125° ambient	1	\$1.79 ea	100	F133	flow assembly, 125° ambient	1	\$1.79 ea
27	E519	heating rod, 12.00W, 115V	1	\$0.99 ea	101	A972	flow, flow assembly, 125° ambient	1	\$1.79 ea	101	A972	flow, flow assembly, 125° ambient	1	\$1.79 ea
28	B107	elbow, brass, 1/4" x 1/4" x 1/4" [tp]	2	\$0.99 ea	102	G091	gasket, 7" vac, id	1	\$1.79 ea	102	G091	gasket, 7" vac, id	1	\$1.79 ea
29	B108	elbow, brass, 1/4" hex, hex	6	\$0.99 ea	103	F153	flange, loc, 1/2" fl x 1/2"	1	\$3.29 ea	103	F153	flange, loc, 1/2" fl x 1/2"	1	\$3.29 ea
30	AH154	hole, 3/8" x 5" (ONL)	1	\$0.99 ea	104	H226	spout, drain, 45 degree	1	\$3.19 ea	104	H226	spout, drain, 45 degree	1	\$3.19 ea
31	B103	elbow, brass, 90 deg, 1/4"m/c	5	\$4.49 ea	105	F123	valve, drain, 1/2"	1	\$2.49 ea	105	F123	valve, drain, 1/2"	1	\$2.49 ea
32	B113	feet, brass, 1/8" id	1	\$0.99 ea	106	H135	gasket, 1/2" m/c x 2" m/c	1	\$3.99 ea	106	H135	gasket, 1/2" m/c x 2" m/c	1	\$3.99 ea
33	B143	odometer, brass, 3/8" fl x 1/4" m/c	1	\$0.99 ea	107	E126	elbow, flow assembly, 125° ambient	1	\$0.99 ea	107	E126	elbow, flow assembly, 125° ambient	1	\$0.99 ea
34	A1120	sol, brass, 1/4" x 1/4" x 1/4" [tp]	1	\$0.99 ea	108	G096	gasket, pressure, 1000PSI, 100PSI	1	\$0.99 ea	108	G096	gasket, pressure, 1000PSI, 100PSI	1	\$0.99 ea
35	B259	qd, brass, 1/4" lgnd x m/c	1	\$0.99 ea	109	E111	hose, pulse, 3/8" x 3/4"	2	\$3.19 ea	109	E111	hose, pulse, 3/8" x 3/4"	2	\$3.19 ea
36	B260	qd, brass, 1/4" m/c x m/c	1	\$0.99 ea	110	E115	switch, rocker, 2 position	3	\$1.79 ea	110	E115	switch, rocker, 2 position	3	\$1.79 ea
37	AH184	hose, puote, 3/8" x 1/2" (ONL)	2	\$0.99 ea	111	E156	switch, rocker, 2 position	1	\$1.79 ea	111	E156	switch, rocker, 2 position	1	\$1.79 ea
38	B452	elbow, brass, 90 deg, 3/8" m/c x 1/4" m/c	3	\$4.49 ea	112	H189	vacuum, 10-32x 1/2" SHCS, clear	1	\$0.99 ea	112	H189	vacuum, 10-32x 1/2" SHCS, clear	1	\$0.99 ea
39	E229A	qd, brass, 1/4" lgnd x b1	3	\$1.99 ea	113	H162	Cuff-LyNk, 1/2" m/c x 2" m/c	1	\$0.99 ea	113	H162	Cuff-LyNk, 1/2" m/c x 2" m/c	1	\$0.99 ea
40	B26A	qd, brass, 1/4" m/c x b1	3	\$1.99 ea	114	F1246	screw, 8-32 x 1/8" SHCS, clear, block	2	\$0.99 ea	114	F1246	screw, 8-32 x 1/8" SHCS, clear, block	2	\$0.99 ea
41	C313A	pump, CAT, 50' 15psi, 120/240v	1	\$0.99 ea	115	H102D	gauge, pressure, 2000 PSI	1	\$0.99 ea	115	H102D	gauge, pressure, 2000 PSI	1	\$0.99 ea
42	B186	elbow, brass, 90 deg, 3/8" m/c x 3/8" m/c	2	\$0.99 ea	116	A93	hose, pulse, 3/8" x 3/4"	1	\$4.99 ea	116	A93	hose, pulse, 3/8" x 3/4"	1	\$4.99 ea
43	B105	bracing, brass, 8/8" m/c x 1/4"	1	\$0.99 ea	117	B156	mult, 1/4" rel	1	\$1.79 ea	117	B156	mult, 1/4" rel	1	\$1.79 ea
44	PH1615	sol, brass, 1/2" lgnd x 100ps	1	\$0.99 ea	118	H1212	flap, washer, 21/16" D x 1/16" O.D.	2	\$0.99 ea	118	H1212	flap, washer, 21/16" D x 1/16" O.D.	2	\$0.99 ea
45	H154	bracket, regulator, panel mount	1	\$0.99 ea	119	E373	level switch, vacuum-shut-off, eat threads	1	\$1.79 ea	119	E373	level switch, vacuum-shut-off, eat threads	1	\$1.79 ea
46	B173	female, 1/2" brass	2	\$0.99 ea	120	H1503	vac support, 3 stage, 3.25" no threads	6	\$3.99 ea	120	H1503	vac support, 3 stage, 3.25" no threads	6	\$3.99 ea
47	B160	adapter, brass, 1/2" carb x 3/8" raw, bar end	1	\$0.99 ea	121	H076	bolt, 1/4-20 x 1" zinc finish	6	\$0.99 ea	121	H076	bolt, 1/4-20 x 1" zinc finish	6	\$0.99 ea
48	PH164-20	sol, brass, 1/2" carb x 3/8" raw, bar end	1	\$0.99 ea	122	C021A	bracket, 1/2" carb, vacuum	2	\$1.79 ea	122	C021A	bracket, 1/2" carb, vacuum	2	\$1.79 ea
49	B170	female, 1/4" brass	3	\$0.99 ea	123	C004	bracket, vacuum motor	2	\$0.99 ea	123	C004	bracket, vacuum motor	2	\$0.99 ea
50	B119	filter, strainer, 1/4"	1	\$0.99 ea										
51	B152	elbow, brass, 90 deg, 1/4" barb x 1/4" m/c	1	\$0.99 ea										
52	H144	bracket, regulator, panel mount	1	\$0.99 ea										
53	B127	plug, brass, 1/4" m/c, hex	1	\$0.99 ea										
54	C313C	regulator, 45 psi, slide, wire sensing	1	\$0.99 ea										
55	H170	sol, 1/2" carb x 1/2" sear, for Komp, inc	2	\$0.99 ea										
56	H112	bracket, rear, 1/2" barb	1	\$0.99 ea										
57	H168	brass, 1/2" carb x 3/4" serialized hex lange, zinc	8	\$0.99 ea										
58	H124	Cuff-LyNk, 2" m/c x 1/4" female cuff	2	\$0.99 ea										
59	H194	coupler, 2" carb x 2" carb, length, 3/8"	2	\$0.99 ea										
60	H177	crimp, tube, 2" carb	4	\$1.49 ea										
61	PH628-20	vac, hose, 2" wire reinforced	2	\$0.99 ea										
62	P132	soft, carb, speedster	2	\$0.99 ea										
63	H130A	bracket, "U"	1	\$0.99 ea										
A	H161-236	clear tubing, 1/2" OD, 3/8" ID, faucet fill	1	\$0.99 ea										
64	H178	faucet, fill	1	\$0.99 ea										
65	G018	cover, 4" carb (tp)	1	\$12.99 ea										
66	F03	cover, 4" carb (tp)	1	\$12.99 ea										
67	H111	bot, 1/4-20 x 1" barb, 1/4" barb, 1/4" barb	2	\$0.99 ea										
68	H011	vac, motor, 1/4" barb, 1/4" barb, 1/4" barb	6	\$0.99 ea										
69	G032	vac, motor, 1/4" barb, 1/4" barb, 1/4" barb	6	\$0.99 ea										

Order parts at: [www.mytee.com/products/product.php?id=1003DX](http://www.mytee.com/products/product.php?id=1003DX)

Part prices are subject to change.



ITEMS NOT SHOWN	
PART NO.	DESCRIPTION
G005	pigtail, wire formed, horse
H230	scREW, 10-32 x 1/2" plain pan head, #5/8
H141	Off-LyNk, 2" hose x 2" fer
E530	power cord, ext, 50', 120s black
E50	Cuff-LyNk, 2" hose x 2" fer
H112	stop sign, regular cut, printed
AD1003DX	manual speedster

SEE DWG. NO. D REV. E FOR DETAILS

SCALE 1:48

1

2

3

4

5

6

7

8

9

10

11

12


13

14

15

16


# 1003DX SPEEDSTER PARTS & PRICING




mytee PRODUCTS, INC.	
NAME M.Garcia	DATE 10/20/13
CHECKED	TITLE 888-577-1791
COMMENTS	speedster
PROPERTY AND CONFIDENTIAL. THE INFORMATION CONTAINED IN THIS DRAWING IS THE PROPERTY OF MYTEE PRODUCTS, INC., AND IS RESTRICTED REPRODUCTION, USE, OR DISCLOSURE WITHOUT THE EXPRESS WRITTEN CON- SENT OF MYTEE PRODUCTS, INC. © MYTEE PRODUCTS, INC. 2013	SHEET 2 OF 3
SIZE DWG. NO. REV <b>C 1003DX E</b>	SCALE: 1:48 DO NOT SCALE DRAWING

# 1003DX SPEEDSTER WIRING SCHEMATIC

Speedster 1003DX




## 1005DX SPEEDSTER® FRONT




1. Switch plate  
2. Easy faucet fill  
3. Solution lid  
4. Female quick disconnect  
5. Front handle  
6. Front vent  
7. Pressure Regulator  
8. Prime Valve  
9. 2" Male Cuff-Lynx™  
10. Recovery lid

## 1005DX SPEEDSTER® BACK




11. Push handle  
12. Recovery tank  
13. Drain valve  
14. Dual Power cords  
15. 12" Rear wheels  
16. Back vent  
17. 5" locking casters  
18. Solution tank


## 1005DX SPEEDSTER® ITEMS INCLUDED



H110 Cuff-Lynx™  
2" Hose Adapter



H141 Cuff-Lynx™  
2" Hose Reducer to 1.5"




H375 - Hose Hanger  
(4) screws



H226 Drain Elbow

## 1005DX SPEEDSTER® CORD


**Left cord:** Powers power Vac 2.  
**Right cord:** Powers Vac 1 & Pump.



Plug each power cord into a separate, 20A grounded wall outlet. **Outlets must be on two separate breakers.** When the amber light on the switch plate illuminates, the machine is on separate circuits (not necessarily 20A circuits). You can identify the primary cord by the yellow tag.


# 1005DX SPEEDSTER

## 1005DX SPEEDSTER® VAC/SOL HOSE CONNECTIONS




Attach one end of a solution hose to a wand or other tool, the other end to the Speedster's® front quick disconnect. Attach one end of a vacuum hose to the tool, the other end to the Speedster's® Cuff-Lynx™ vacuum hose port.

## 1005DX SPEEDSTER® SWITCHES




"On" switches are located on the plate in front of the machine. To use vacuums, turn on Vac 1 and Vac 2 switches. To use pump, turn on Pump switch. Bottom right switch has no use.

## 1005DX SPEEDSTER® FILL SOLUTION TANK




Lift lid and manually fill the solution tank or use the easy faucet fill.

## 1005DX SPEEDSTER® PRIME VALVE & PRESSURE REGULATOR




Prime the pump by turning the valve to the Prime position (as shown above) for 30 seconds, then turn right to the Run position. Turn the Pressure Regulator to the left to decrease water pressure. Turn the Pressure Regulator to the right to increase water pressure.

## 1005DX SPEEDSTER® FILTER MAINTENANCE




Check and clean the vacuum stack filters and solution tank filter daily by twisting off, rinsing with clean water and replacing.

## 1005DX SPEEDSTER® FLOAT SWITCH




The Speedster® is equipped with an electronic float switch inside the recovery tank. The recovery float switch is activated by rising water to prevent suction into the vacuum stacks damaging the motors.

## 1005DX SPEEDSTER® DUMP VALVE & LOCKING CASTERS



Above, empty the recovery tank by attaching the 45° drain elbow to the drain spout in back. Lift up the dump valve and empty the tank. Below, locking casters help keep the machine remain stationary during use.


## MYTEE® SYSTEM MAINTAINER



Weekly flushing of the solution system with Mytee® System Maintainer helps keep lines clean and prevents chemical build-up, improving pump life, performance and pressure.

# 1005DX SPEEDSTER PARTS & PRICING

ITEM NO.	PART NO.	DESCRIPTION	QTY.	MSRP	ITEM NO.	PART NO.	DESCRIPTION	QTY.	MSRP	
1	H296	guard, cooling fan, wire	3	\$2.99 ea	63	PH634-36	sol hose, 1/4", 300 PSI	1	\$6.49 ft	
2	H243	screw, #10 x 5/8" hex head zinc	12	\$0.99 ea	64	B216	nipple, brass, 3/8" x close	1	\$1.99 ea	
3	H273	nut, #10-32 zinc	4	\$0.99 ea	65	H299	washer, 11/16" id x 1-1/2" od x .075", s/s	4	\$0.99 ea	
F	E370	controller, water level, dual pump or vac	1	\$94.99 ea	66	B210	bushing, brass, 1/2"mpf x 3/8" tpi, hex	1	\$2.49 ea	
F	5	H186	screw, 10-32 x 3/4", phill flat full thread	2	\$0.99 ea	67	B119A	filter, strainer, 1/2"	1	\$6.49 ea
6	H378	bracket, front hinge, spifb	1	\$8.99 ea	68	AH120	sol hose, 1/4" x 24 1/2" (OAL), f x fsw, 3000psi	1	\$35.99 ea	
7	H210	washer, 1/4" flat, s/s	26	\$0.99 ea	69	H422	plug, dome 3/8", black	2	\$1.00 ea	
8	H213	washer, 1/4" lock, s/s	10	\$0.99 ea	70	P957A	plug	1	\$1.99 ea	
9	H201	bolt, 1/4-20 x 1/2", hex head, zinc	2	\$0.99 ea	71	E515	switch, rocker 2 position	3	\$13.99 ea	
10	H216	nut, lock, 1/4-20, nylon insert, s/s	14	\$0.99 ea	72	H389	screw, 10-32 x 1/2" SC5, alloy	4	\$0.99 ea	
11	H316	bolt, 1/4-1/2", hex head, zinc	2	\$0.99 ea	73	H612	Washer, #8, flat regular	3	\$0.99 ea	
12	H342	bolt, 1/4-20 x 1" hex head, 2000 psi	8	\$0.99 ea	74	H308D	gauge, pressure 2000 PSI	1	\$38.99 ea	
13	H666	caster, 5", black hub & gray tread	2	\$23.99 ea	75	E51B	light, indicator, 125v (amber)	1	\$9.99 ea	
14	P731	base, speedster	1	\$141.99 ea	76	B156	nut, 1/4" npf	1	\$1.99 ea	
E	15	H254	washer, axle, cut 1/2" id	4	\$0.99 ea	77	H337	plate, switch, 1003DX, 1005DX	1	\$8.99 ea
16	H371	axle, 18.03" x 50" dia	1	\$9.99 ea	78	H212	flat washer, 9/16"ID x 1 1/16"OD	2	\$0.99 ea	
17	H251	wheel, 12"	2	\$41.99 ea	79	B207	elbow, washer, 1/4"tpi x 1/4" fpt	1	\$5.99 ea	
18	H042	c-clip, 12mm, external	2	\$0.99 ea	80	E373	level switch, vacuum shut-off, rear threads	1	\$13.99 ea	
19	E550	power cord, digital, 30", 12/3, black	2	\$11.49 ea	81	B103	elbow, brass, 90 deg, 1/4"mpf x 1/4" fpt	1	\$4.49 ea	
20	H220	fitting, strain relief, cord	2	\$3.19 ea	82	P733	vac tank, speedster	1	\$190.99 ea	
21	H221	nut, lock, 1/2" steel	2	\$1.99 ea	83	G091	gasket, 7", vac lid	1	\$11.99 ea	
22	H912	bracelet, rear, fb/spy	1	\$9.99 ea	84	C090	lid, vac tank, clear, 7"	1	\$36.99 ea	
23	H307	washer, star, 1/4" steel zinc	2	\$0.99 ea	85	H304	screw, #8 x 5/8" phil oval, s/s	6	\$0.99 ea	
24	H770	bolt, 1/4-20 x 1/2" serrated hex flange, zinc	8	\$0.99 ea	86	PH633-1	pipe, pvc, 1/4" tpif x 1/4" fpt	2	\$4.99 ft	
D	25	H202	bolt, 1/4x20x3/4" hex head	4	\$0.99 ea	87	G003	filter, foam, 2" x 50" o.d.	2	\$1.99 ea
26	B246	plug, brass, 1/2" deg, 3/8"mpf x 3/8" fmpf	1	\$1.99 ea	88	P097	screen, mesh filter, 1-1/2" dia	2	\$4.99 ea	
27	B186	elbow, brass, 90 deg, 3/8"mpf x 3/8" fmpf	2	\$8.99 ea	89	P502	adapter, pvc, 1-1/2" mpf x 1-1/2" fms	2	\$5.00 ea	
28	B105	bushing, brass, 3/8"mpf x 1/4"	1	\$13.99 ea	90	PH633-06	PIPE, 1-1/2" x 6" PVC	2	\$4.99 ft	
29	B260A	qd, brass, 1/4" mpdf x fpt	2	\$8.99 ea	91	P503	adapter, 1.5" pvc, 45 deg, fslip x fslip	4	\$3.29 ea	
30	B259A	qd brass, 1/4" fad x fpt	2	\$15.99 ea	92	PH633-03	pipe, pvc, 1-1/2"	2	\$4.99 ft	
31	B644	adapter, brass, 1/2" barb x 1/4" mpf	1	\$2.49 ea	93	PH633-4	pipe, pvc, 1-1/2"	2	\$4.99 ft	
32	PH615-37	sol hose, 1/2", kuri, 100 fsi	1	\$1.99 ea	94	P520	adapter, pvc, 1-1/2" mpf x 1-1/2" fms	2	\$2.99 ea	
C	33	B173	female, 1/2", brass	2	\$0.99 ea	95	H314	nut, lock, 1-1/2", steel	2	\$1.99 ea
34	B160	adapter, brass, 1/2" barb x 3/8" fsw, ball end	1	\$3.49 ea	96	H225	valve, drain, 1-1/2"	1	\$20.99 ea	
35	B652	elbow, brass, 90 deg, 3/8"mpf x 3/8" fmpf	1	\$8.49 ea	97	H226	spout, drain, 45 degree	1	\$13.99 ea	
36	B107	nipple, brass, 1/4"m, 4"	4	\$3.19 ea	98	A296	elbow, inlet assembly 2"	1	\$15.99 ea	
37	B643	adapter, brass, 3/8"mpf x 1/4" mpnf	1	\$4.99 ea	99	G083	gasket, 2", inlet	1	\$2.49 ea	
38	B113	tee, brass, 1/4" fpt	1	\$6.99 ea	100	H135	Cuff-Lynx, 2" m cuff x 2" mpf	1	\$3.99 ea	
39	AH184	hose, pulse Blk 49" (OAL), 1/4"tswl x 1/4"tswl	1	\$19.99 ea	101	H390A	valve, bracket, "L"	2	\$6.99 ea	
40	C13A	pump, CAT, 50-500 PSI, 120V/240V	1	\$599.99 ea	102	G004	gasket, vacuum motor	2	\$8.99 ea	
41	H768	bolt, 1/4x20x3/4" serrated hex flange, zinc	2	\$0.99 ea	103	H096	bolt, hex, 1/4-20 x 4", zinc Finish	6	\$0.99 ea	
42	H211	washer, 1/4" id x 1" od, flat, s/s	6	\$0.99 ea	104	C302A	vac motor, 3-stage hp, 120V, 145"	2	\$48.99 ea	
43	G052	washer, buna 1-1/8" od x 3/16" id	6	\$1.99 ea	105	H503	vac support, 3 stage, 3.25", no thirds	6	\$3.99 ea	
44	H485	handle, breeze and dx	1	\$6.99 ea	106	H203	bolt, 1/4-20 x 1-1/4"	2	\$0.99 ea	
45	PH612-36	clear tubing, 1/2" OD x 3/8" ID, faucet fill	1	\$1.99/ft	107	H215	nut, hex, 1/4-20 s/s	2	\$62.99 ea	
46	H178	cover, sol tank (sp)	1	\$10.99 ea	108	E564	controller, circuit light	1	\$62.99 ea	
B	47	G018	sol tank, speedster	1	\$1299 ea					
48	P732	vac hose, 2" wire reinforced, gray	2	\$8.99/ft						
49	PH628-24	vac hose, 2" wire reinforced, gray	2	\$8.99/ft						
F	50	H217	clamp, hose, 2 1/4" dia	4	\$1.49 ea					
51	H194	coupler, 2" dia x 2 5/8" length, s/s	2	\$10.00 ea						
52	H124	Cuff-Lynx, 2" mpf x 2" female cuff	2	\$3.99 ea						
53	PH634-20	sol hose, 1/4" 300 PSI	1	\$6.49 ft						
54	B109	adapter, brass, 1/4" barb x 1/4" mpf	2	\$1.99 ea						
55	H266	screw, 10-32 x 3/4" phil pan head, zinc	4	\$0.99 ea						
56	H484	plate, mounting, QD	1	\$4.99 ea						
57	AH203	hose, pulse Blk 49" (OAL), 1/4"tswl x 1/4"tswl	1	\$19.99 ea						
A	58	C313C	regulator, 450 psi, silver spring	1	\$86.99 ea					
59	B135	tee, brass, 1/4" mpf	1	\$5.49 ea						
60	B102	qd, brass, 1/4" mpf	1	\$17.99 ea						
61	B456	ball valve, 1/4"	1	\$13.49 ea						
62	B170	female, 1/4" brass	2	\$0.99 ea						



## ITEMS NOT SHOWN

PART NO.	DESCRIPTION	QTY.	MSRP
G008	piglet filet	1	\$6.29 pak
H375	hanger, wire formed, hose	1	\$10.99 ea
H230	screw, 10-32 x 1/2" phil pan head, s/s	2	\$0.99 ea
H141	Cuff-Lynx, 2" to 1.5" reducer	1	\$3.99 ea
E530	power cord, ext 50', 12/3 black	2	\$74.99 ea
H110	Cuff-Lynx, 2" hose x 2" fmv swivel Cuff-Lynx	1	\$3.99 ea
AD127	stop sign, register your product	1	
ADM-SPEEDSTERS	manual, speedsters	1	

SHEET DWG. NO.	REV	TITLE:	SCALE: 1:18	SCALING	SHAPING	1 OF 3
C	D	speedster				

Order parts at: [www.mytee.com/products/product.php?id=1005DX](http://www.mytee.com/products/product.php?id=1005DX)

Part prices are subject to change.

PROPRIETARY AND CONFIDENTIAL  
DRAWINGS ARE THE EXCLUSIVE PROPERTY OF  
KODAK. THEY ARE TO BE KEPT CONFIDENTIAL  
AND ARE NOT TO BE COPIED OR USED  
WHENEVER PRACTICALLY POSSIBLE.  
KODAK RESERVES THE RIGHT TO  
SUITE FOR PRACTICAL USE  
WHENEVER PRACTICALLY POSSIBLE.

868-672-19


PRINTED ON 10/20/2013

DRAWN BY M. GRIFFITHS

CHECKED


DATE 10/20/2013

# 1005DX SPEEDSTER PARTS & PRICING




# 1005DX SPEEDSTER WIRING SCHEMATIC

**1005DX  
115 Volt System**



1/27/2014



## Dear Customer:

Congratulations on the purchase of your new Speedster® Extractor. As you are already aware, the scene of the equipment world is becoming more high tech, and we at Mytee Products Inc. strive to keep you on the cutting edge with superior quality and technology.

Keep in mind that the Speedster® Extractor is a machine, so neglect or abuse will cause unnecessary damage and void the warranty. However with simple maintenance the Speedster® will give quality performance for many years to come.

If warranty questions arise, please consult user manual or get in touch with your distributor. If you have questions about maintenance, replacing parts or ordering parts, please call an authorized Mytee Products Inc. Service Center. To see an updated list, visit our website at [www.mytee.com](http://www.mytee.com)

Before you begin using, please read your manual thoroughly.

Sincerely,  
Mytee Customer Care Dept.

## Grounding Instructions

This machine must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electrical shock. This machine is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be plugged into an appropriate outlet that is properly installed in accordance with all local code and ordinances. Do not remove ground pin; if missing, replace plug before use.



Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the machine. If it will not fit the outlet, have a proper outlet installed by a qualified electrician.

This appliance is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated in Figure 1 below. A temporary adapter illustrated in Figures 2 and 3 may be used-to connect this plug to a 2-pole receptacle as shown in Figure 2 if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet (Figure 1) can be installed by a qualified electrician. The green colored rigid ear, tab or the like extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw. Grounding adapters are not approved for use in Canada.

Replace the plug if the grounding pin is damaged or broken.

The Green (or GreenYellow) wire in the cord is the grounding wire. When replacing a plug, this wire must be attached to the grounding pin only.

DO NOT use extension cords.

**Please Note for America use only**




Figure 1



Figure 2

Figure 3

## Parts and Service

Repairs, when required, should be performed by Mytee service personnel or Mytee authorized Service Center using Mytee original replacement parts and accessories. Call Mytee for repair parts or service. Please

specify the Model and Serial Number when discussing your machine.

## Name Plate

The Model and Serial Number of your machine are shown on the name plate located on the inside of the machine. This information is needed when ordering repair parts for the machine. Use the space provided on the front cover to note the Model and Serial Number of your machine for future reference.

## Unpacking the Machine

When the machine is delivered, carefully inspect the shipping carton and the machine for damage. If damage is evident, save the shipping carton so that it can be inspected by the carrier that delivered it. Contact the carrier immediately to file a freight damage claim.

## Caution and Warnings

### Symbols

Mytee uses the symbols below to signal potentially dangerous conditions. Always read this information carefully and take the necessary steps to protect personnel and property.



### DANGER

Is used to warn of immediate hazards that will cause severe personal injury or death.



### WARNING

Is used to call attention to a situation that could cause severe personal injury.



### CAUTION

Is used to call attention to a situation that could cause minor personal injury or damage to the machine or other property. When using an electrical appliance, basic precautions should always be followed, including the following: Read all instructions before using this machine. This product is intended for commercial use only.



### WARNING

To reduce the risk of fire, electrical shock, or injury:

1. Read all instructions before using equipment.
2. Use only as described in this manual. Use only manufacturer's recommended attachments.
3. Always unplug power cord from electrical outlet before attempting any adjustments or repairs.
4. Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
5. Do not pull or carry by cord. Do not close a door on cord or pull cord around sharp edges or corners.
6. Do not run appliance over cord. Keep cord away from heated surfaces.
7. Do not use with damaged cord or plug. If cord is damaged, repair immediately.
8. Do not use outdoors or on wet surfaces and or standing water.
9. Always unplug or disconnect the appliance from power supply when not in use.
10. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
11. Do not use in areas where flammable or combustible material may be present.
12. Do not leave the unit exposed to harsh weather elements. Temperatures below freezing may damage components and void warranty.
13. Use only the appropriate handles to move and lift unit. Do not use any other parts of this machine for this purpose.
14. Keep hair, loose clothing, fingers, and all parts of the body away from all openings and moving parts.
15. Use extra care when using on stairs.
16. To reduce the risk of fire or electric shock, do not use this machine with a solid-state speed control device.

# GENERAL INFORMATION

17. The voltage and frequency indicated on the name plate must correspond to the wall receptacle supply voltage.
18. When cleaning and servicing the machine, local or national regulations may apply to the safe disposal of liquids which may contain: chemicals, grease, oil, acid, alkalines, or other dangerous liquids.
19. Do not leave operating unattended.

## Preparation

1. Remove furniture and other items from the area you are going to clean.
2. Vacuum carpet and upholstery, and remove debris.
3. Protect cabinets, walls and painted surfaces with drop cloths or plastic.
4. Inspect power cords for damages.

## Operating Instructions

1. Fill the solution tank.
2. Attach one end of a solution hose to a wand or other tool, the other end to the Speedster's® front quick disconnect.
3. Attach one end of a vacuum hose to the tool, the other end to the Speedster's® Cuff-Lynx™ vacuum hose port.
4. Plug in power cords.
  - **1000DX-200 models** – Plug single cord into single, 20A grounded wall outlet.
  - **1001DX-200 models** – Using two separate circuits/breakers, plug the left power cord into 20A grounded wall outlet to turn on Vac 2 and Heater 2. Plug the right power cord into separate 20A grounded wall outlet to turn on Vac 1, Heater 1 and Pump.
  - **1003DX models** – Using two separate circuits/breakers, plug the left power cord into 20A grounded wall outlet to turn on Vac 2 and Heater 2. Plug the right power cord into separate 20A grounded wall outlet to turn on Vac 1, Heater 1 and Pump.
  - **1005DX models** – Using two separate circuits/breakers, plug the left power cord into 20A grounded wall outlet to turn on Vac 2. Plug the right power cord into separate 20A grounded wall outlet to turn on Vac 1 and Pump.
- The amber light indicator on the switch plate will illuminate brightly when cords are plugged into two separate circuits. Do not use extension cords longer than 50 feet.
5. Turn on switches.
  - 1000DX-200, 1005DX models – Turn on Vac 1, Vac 2 and Pump switches.
  - 1001DX-200 and 1003DX – Turn on Vac 1, Vac 2 and Pump switches. Turn on Heater switch if heat is being used. Wait several minutes for water to heat. Heater switch has three positions: Off (middle); 1,000 watts using one heater (left); and 2,000 watts using two heaters (right). Red lights on panel display indicate watts selected: one light = 1,000 watts; two lights = 2,000 watts; no lights = heaters are off.
  - 6. 1003DX and 1005DX models – Prime Valve and Pressure Regulator are located on the lower front of the extractor. To prime the pump, turn the valve to the Prime position for 30 seconds, then turn horizontally to the Run position. Turn the Pressure Regulator to the left to decrease the water pressure. Turn to the right to increase water pressure. Level will be visible on the pressure gauge. Monitor while adjusting, using Pressure Gauge on Switch Panel.
  - 7. Begin cleaning. Make two dry passes to every wet pass. Work away from cords to avoid damage. To clean heavily soiled areas, repeat cleaning from a different direction.
  - 8. Use a foam control solution in the recovery tank to prevent motor damage and check for foam build-up in recovery and solution tanks.
  - 9. Empty the recovery tank as needed when the internal ball float automatically shuts off the vacuum. Attach the 45° drain elbow to the drain spout in back. Lift up the dump valve and empty tank.
  - 10. To relieve water pressure from the solution hose before disconnecting it, squeeze the tool's trigger five seconds after turning the power switches off.
  - 11. Once machine is off, unplug power cords. Remove solution and vacuum hoses. Empty the recovery tank by attaching the 45° drain elbow to the drain spout in back. Lift up the dump valve and empty tank.
  - 12. 1003DX and 1005DX models – Water remaining in the solution tank can be emptied by turning the Prime Valve to the right to move water into the recovery tank. Empty recovery tank.

**Please note:** Your pump features a pressure switch, to protect vital components. A minimum spray jet size of 02 needed for use with this pump. Using a jet size smaller than this can cause back-pressure to the pump, leading to an over-heat condition. Make sure that your tool has a jet size of 02 or larger prior to use.

## After Use

1. Before storing machine, drain, rinse and dry tanks and vacuum hose of water and solution.
2. Store in a dry are in the upright position.
3. Open recover tank cover to promote air circulation.
4. Store indoors in a dry area. If storing in freezing temperatures, make sure the machine and solution system are completely drained and dry.

## Maintenance Schedule

Latches are located in back to open tank for internal maintenance. To keep machine in good working condition, follow machine's daily and weekly maintenance procedures. Check valves and relief valves should be replaced annually.

Maintenance item	Daily	Once a week
Clean and inspect tanks.	x	
Clean and inspect hoses.	x	
Check and clean internal filters by twisting off, rinsing with clean water and replacing.	x	
Check power supply cable.	x	
Clean machine with all-purpose cleaner and cloth.	x	
Check spray nozzles.	x	
Flush solution system with Mytee® System Maintainer.		x
Remove and float shut-off screen from tank and clean. Simply pull off.		x
Inspect vacuum hoses for holes and loose cuffs.		x
Inspect spray pattern for clogging. If clogged, remove spray tips and soak them in a recommended liquid neutralizer for up to six hours. To remove spray tip, twist spray tip body counter-clockwise.		x
Lubricate wheels with water resistant oil.		x
Inspect machine for water leaks and loose hardware.		x

## Trouble Shooting

**There is no power.**

1. Plug machine in proper outlet.
2. If using two cords, make sure each is plugged into a separate circuit.
3. Check circuit breaker. Reset circuit breaker, other items should not run on the same circuit as the machine. Outlet must be a 20-amp circuit.

## Pump does not work properly

1. Snap quick disconnects firmly together.
2. Check solution tank; may be empty.
3. Jets clogged, remove jet and flush clean.
4. Filters clogged, remove filters and rinse clean with water.
5. Heater is blocked; flush out with Mytee's® System Maintainer.
6. If brass check valve is stuck, replace valve.
7. Check pump wire. May need to reconnect wire.
8. Switch plate may need to be replaced.
9. If pump motor brushes are worn, replace pump.

**\*A minimum spray jet size of 02 needed for use with this pump.**

## 1001DX-200 or 1003DX heater does not work properly

1. If sensor mounted on the heater has popped, reset sensor by pushing in button.
2. Heating element may need to be replaced.

## Vacuum motor does not work properly

1. Check that hose is tightly connected.
2. Close drain hose valve completely.
3. Secure the vacuum tank tightly.

4. If electronic switch is shut off, empty vacuum tank of all wastewater.
5. If water is coming out of the vacuum motor, use a low foaming detergent.
6. Clean upholstery tool or floor wand jets.

### FAQs

Q: How much do the Speedster® Series extractors weigh and what are the dimensions?

A: All Speedsters

Machine Dimensions: 28" x 18 1/4" x 40"

Shipping Dimensions: 29 1/2" x 19 1/4" x 46 1/2"

1000DX-200 – Machine Weight: 83 lbs.

Shipping Weight: 104 lbs.

1001DX-200 – Machine Weight: 94 lbs.

Shipping Weight: 124 lbs.

1003DX – Machine Weight: 122 lbs.

Shipping Weight: 150 lbs.

1005DX – Machine Weight: 113 lbs.

Shipping Weight: 140 lbs.

Q: What comes standard with Speedsters™ extractors?

A: Hose hanger with four screws, two Cuff-Lynx™ Model Numbers: H141 Reducer and H110 Coupler Swivel, and 45° drain elbow.

Q: Does Mytee® recommend tools for this machine?

A: All upholstery tools and wands can be used with the Speedster® series.

Q: Is there anything I can do to increase the expected life of my machine?

A: Running the vacuum motors with the tank empty and lid off will allow excess moisture in the vacs to dry off. You should also run Mytee's® System Maintainer through the system to keep the hoses, pump, and heater clean and free of debris..

# **NOTES**

# **NOTES**

# NOTES



Mytee Products Inc.  
13655 Stowe Dr.  
Poway, Ca. 92064  
[www.mytee.com](http://www.mytee.com)

© 2015 Mytee Products Inc.  
Printed in the U.S.A.